

80x86 Integer Instruction Set Timings (8088 - Pentium)

Source: http://www.quantasm.com/opcode_i.html

Legend:

General

acc = AL, AX or EAX unless specified otherwise
reg = any general register
r8 = any 8-bit register
r16 = any general purpose 16-bit register
r32 = any general purpose 32-bit register
imm = immediate data
imm8 = 8-bit immediate data
imm16 = 16-bit immediate data
mem = memory address
mem8 = address of 8-bit data item
mem16 = address of 16-bit data item
mem32 = address of 32-bit data item
mem48 = address of 48-bit data item
dest = 16/32-bit destination
short = 8-bit destination

Integer instruction timings:

n - generally refers to a number of repeated counts
m - in a jump or call;
 286: bytes in next instruction
 386/486: number of components
 (each byte of opcode) + 1 (if immed data) + 1 (if displacement)
EA = cycles to calculate the Effective Address
8088/8086:
 base = 5 BP+DI or BX+SI = 7 BP+DI+disp or BX+SI+disp = 11
 index = 5 BX+DI or BP+SI = 8 BX+DI+disp or BP+SI+disp = 12
 disp = 6 segment override = +2
286 - 486:
 base+index+disp = +1 all others, no penalty

Instruction length:

The byte count includes the opcode length and length of any required displacement or immediate data. If the displacement is optional, it is shown as d() with the possible lengths in parentheses. If the immediate data is optional, it is shown as i() with the possible lengths in parentheses.

pairing categories for Pentium:

NP = not pairable
UV = pairable in the U pipe or V pipe
PU = pairable in the U pipe only
PV = pairable in the V pipe only

Instruction formats, clock cycles and Pentium® Pairing info

AAA	ASCII adjust after addition	bytes	8088	186	286	386	486	Pentium
			1	8	3	4	3	3 NP
	Example:		aaa					

AAD	ASCII adjust AX before division (second byte is multiplier)	bytes	8088	186	286	386	486	Pentium
			2	60	14	19	14	10 NP

Example: aad

AAM ASCII adjust AX after multiply (second byte is divisor)
bytes 8088 186 286 386 486 Pentium
2 83 19 16 17 15 18 NP

Example: aam

AAS ASCII adjust AL after subtraction
bytes 8088 186 286 386 486 Pentium
1 8 7 3 4 3 3 NP

Example: aas

ADC Integer add with carry
operands bytes 8088 186 286 386 486 Pentium
reg, reg 2 3 3 2 2 1 1 PU
mem, reg 2+d(0,2) 24+EA 10 7 7 3 3 PU
reg, mem 2+d(0,2) 13+EA 10 7 6 2 2 PU
reg, imm 2+i(1,2) 4 4 3 2 1 1 PU
mem, imm 2+d(0,2) 23+EA 16 7 7 3 3 PU*

acc, imm 1+i(1,2) 4 4 3 2 1 1 PU

* = not pairable if there is a displacement and immediate

Example: adc eax, ebx

ADD Integer addition
operands bytes 8088 186 286 386 486 Pentium
reg, reg 2 3 3 2 2 1 1 UV
mem, reg 2+d(0,2) 24+EA 10 7 7 3 3 UV
reg, mem 2+d(0,2) 13+EA 10 7 6 2 2 UV
reg, imm 2+i(1,2) 4 4 3 2 1 1 UV
mem, imm 2+d(0,2) 23+EA 16 7 7 3 3 UV*

acc, imm 1+i(1,2) 4 4 3 2 1 1 UV

* = not pairable if there is a displacement and immediate

Example: add eax, ebx

AND Logical AND
operands bytes 8088 186 286 386 486 Pentium
reg, reg 2 3 3 2 2 1 1 UV
mem, reg 2+d(0,2) 24+EA 10 7 7 3 3 UV
reg, mem 2+d(0,2) 13+EA 10 7 6 2 2 UV
reg, imm 2+i(1,2) 4 4 3 2 1 1 UV
mem, imm 2+d(0,2) 23+EA 16 7 7 3 3 UV*

acc, imm 1+i(1,2) 4 4 3 2 1 1 UV

* = not pairable if there is a displacement and immediate

Example: and eax, ebx

ARPL Adjust RPL field of selector (286+)
operands bytes 286 386 486 Pentium
reg, reg 2 10 20 9 7 NP
mem, reg 2+d(0-2) 11 21 9 7 NP

Example: arpl ax, bx

BOUND Check array index against bounds (186+)
operands bytes 186 286 386 486 Pentium
reg, mem 4 35 13 10 7 8 NP

Example: bound bx, array

BSF Bit scan forward (386+)
operands bytes 386 486 Pentium

r16, r16	3			10+3n	6-42	6-34	NP
r32, r32	3			10+3n	6-42	6-42	NP
r16, m16	3+d(0,1,2)			10+3n	7-43	6-35	NP
r32, m32	3+d(0,1,2,4)			10+3n	7-43	6-43	NP
Example:	bsf	eax,	[esi]				
BSR Bit scan reverse (386+)							
operands	bytes			386	486		Pentium
r16, r16	3			10+3n	6-103	7-39	NP
r32, r32	3			10+3n	7-104	7-71	NP
r16, m16	3+d(0,1,2)			10+3n	6-103	7-40	NP
r32, m32	3+d(0,1,2,4)			10+3n	7-104	7-72	NP
Example:	bsr	eax,	[esi]				
BSWAP Byte swap (486+)							
operand	bytes				486		Pentium
r32	2				1	1	NP
Example:	bswap	eax					
BT Bit test (386+)							
operands	bytes			386	486		Pentium
reg, reg	3			3	3	4	NP
mem, reg	3+d(0,1,2,4)			12	8	9	NP
reg, imm8	3+i(1)			3	3	4	NP
mem, imm8	3+d(0,1,2,4)+i(1)			6	3	4	NP
Example:	bt	eax,	4				
BTC Bit test and complement (386+)							
operands	bytes			386	486		Pentium
reg, reg	3			6	6	7	NP
mem, reg	3+d(0,1,2,4)			13	13	13	NP
reg, imm8	3+i(1)			6	6	7	NP
mem, imm8	3+d(0,1,2,4)+i(1)			8	8	8	NP
Example:	btc	eax,	4				
BTR Bit test and reset (386+)							
operands	bytes			386	486		Pentium
reg, reg	3			6	6	7	NP
mem, reg	3+d(0,1,2,4)			13	13	13	NP
reg, imm8	3+i(1)			6	6	7	NP
mem, imm8	3+d(0,1,2,4)+i(1)			8	8	8	NP
Example:	btr	eax,	4				
BTS Bit test and set (386+)							
operands	bytes			386	486		Pentium
reg, reg	3			6	6	7	NP
mem, reg	3+d(0,1,2,4)			13	13	13	NP
reg, imm8	3+i(1)			6	6	7	NP
mem, imm8	3+d(0,1,2,4)+i(1)			8	8	8	NP
Example:	bts	eax,	4				
CALL Call subroutine							
operand	bytes	8088	186	286	386	486	Pentium
near	3	23	14	7+m	7+m	3	1 PV
reg	2	20	13	7+m	7+m	5	2 NP
mem16	2+d(0-2)	29+EA	19	11+m	10+m	5	2 NP
far	5	36	23	13+m	17+m	18	4 NP
mem32	2+d(0-2)	53+EA	38	16+m	22+m	17	4 NP
Protected Mode							
operand	bytes			286	386	486	Pentium
far	5			26+m	34+m	20	4-13 NP

mem32	2+d(0-2)		29+m	38+m	20	5-14	NP	
		cycles not shown for calls through call and task gates						
Example:	call	my_function						
CBW	Convert byte to word (AL --> AX)							
	bytes	8088	186	286	386	486	Pentium	
		1	2	2	3	3	3	NP
Example:	cbw							
CWDE	Convert word to dword (386+) (AX --> EAX)							
	bytes				386	486	Pentium	
		1			3	3	3	NP
Example:	cwde							
CWD	Convert word to double (AX --> DX:AX)							
	bytes	8088	186	286	386	486	Pentium	
		1	5	4	2	3	2	NP
Example:	cwd							
CDQ	Convert double to quad (EAX --> EDX:EAX)							
	bytes				386	486	Pentium	
		1			2	3	2	NP
Example:	cdq							
CLC	Clear the carry flag							
	bytes	8088	186	286	386	486	Pentium	
		1	2	2	2	2	2	NP
Example:	clc							
CLD	Clear the direction flag (set to forward direction)							
	bytes	8088	186	286	386	486	Pentium	
		1	2	2	2	2	2	NP
Example:	cld							
CLI	Clear the interrupt flag (disable interrupts)							
	bytes	8088	186	286	386	486	Pentium	
		1	2	3	3	5	7	NP
Example:	cli							
CLTS	Clear task switched flag in CR0 (286+)							
	bytes			286	386	486	Pentium	
		2		2	5	7	10	NP
Example:	clts							
CMC	Complement carry flag							
	bytes	8088	186	286	386	486	Pentium	
		1	2	2	2	2	2	NP
Example:	cmc							
CMP	Compare two operands							
operands	bytes	8088	186	286	386	486	Pentium	
reg, reg	2	3	3	2	2	1	1	UV
mem, reg	2+d(0,2)	13+EA	10	7	5	2	2	UV
reg, mem	2+d(0,2)	13+EA	10	6	6	2	2	UV
reg, imm	2+i(1,2)	4	4	3	2	1	1	UV
mem, imm	2+d(0,2)	14+EA	10	6	5	2	2	UV*
	+i(1,2)							
acc, imm	1+i(1,2)	4	4	3	2	1	1	UV
	* = not pairable if there is a displacement and immediate							
Example:	cmp eax, 3							
CMPS/CMPSB/CMPSW/CMPSD	Compare string operands							
variations	bytes	8088	186	286	386	486	Pentium	
cmplib	1	30	22	8	10	8	5	NP
cmplib	1	-	-	-	10	8	5	NP

cmpsd	1	-	-	-	10	8	5	NP
repX cmpsb	2	9+30n	5+22n	5+9n	5+9n	7+7n*	9+4n	NP
repX cmpsw	2	9+30n	5+22n	5+9n	5+9n	7+7n*	9+4n	NP
repX cmpsd	2	-	-	-	5+9n	7+7n*	9+4n	NP

repX = repe, repz, repne or repnz
 * : 5 if n = 0
 Example: repne cmpsb

CMPXCHG Compare and Exchange (486+)

operands	bytes	486	Pentium
reg, reg	3	6	5 NP
mem, reg	3+d(0-2)	7-10	6 NP

Example: cmpxchg ebx, edx

CMPXCHG8B Compare and Exchange 8 bytes (Pentium+)

operands	bytes	Pentium
mem, reg	3+d(0-2)	10 NP

Example: cmpxchg8b [ebx], edx

CPUID CPU identification (Pentium+)

bytes	Pentium
2	14 NP

Example: cpuid

DAA Decimal adjust AL after addition

bytes	8088	186	286	386	486	Pentium
1	4	4	3	4	2	3 NP

Example: daa

DAS Decimal adjust AL after subtraction

bytes	8088	186	286	386	486	Pentium
1	4	4	3	4	2	3 NP

Example: das

DEC Decrement

operand	bytes	8088	186	286	386	486	Pentium
r8	2	3	3	2	2	1	1 UV
r16	1	3	3	2	2	1	1 UV
r32	1	3	3	2	2	1	1 UV
mem	2+d(0,2)	23+EA	15	7	6	3	3 UV

Example: dec eax

DIV Unsigned divide

operand	bytes	8088	186	286	386	486	Pentium
r8	2	80-90	29	14	14	16	17 NP
r16	2	144-162	38	22	22	24	25 NP
r32	2	-	-	-	38	40	41 NP
mem8	2+d(0-2)	86-96+EA	35	17	17	16	17 NP
mem16	2+d(0-2)	150-168+EA	44	25	25	24	25 NP
mem32	2+d(0-2)	-	-	-	41	40	41 NP

implied dividend	operand	quotient	remainder
AX	/ byte	= AL	AH
DX:AX	/ word	= AX	DX
EDX:EAX	/ dword	= EAX	EDX

Example: div ebx

ENTER Make stack frame for procedure parameters (186+)

operands	bytes	8088	186	286	386	486	Pentium
imm16, 0	3	-	15	11	10	14	11 NP

imm16, 1	4	-	25	15	12	17	15	NP
imm16, imm8	4	-	22+16n	12+4n	15+4n	17+3i	15+2i	NP

n = imm8-1; i = imm8

Example: enter 1, 0

ESC Escape

escape opcodes D8 - DF are used by floating point instructions

HLT Halt

	bytes	8088	186	286	386	486	Pentium
	1	2	2	2	5	4	4 NP

Example: hlt

IDIV Signed divide

operand	bytes	8088	186	286	386	486	Pentium
r8	2	101-112	44-52	17	19	19	22 NP
r16	2	165-184	53-61	25	27	27	30 NP
r32	2	-	-	-	43	43	46 NP
mem8	2+d(0-2)	107-118+EA	50-58	20	22	20	22 NP
mem16	2+d(0-2)	171-190+EA	59-67	28	30	28	30 NP
mem32	2+d(0-2)	-	-	-	46	44	46 NP

implied operand quotient remainder
dividend

AX / byte = AL AH
DX:AX / word = AX DX
EDX:EAX / dword = EAX EDX

Example: idiv ebx

IMUL Signed multiply

			Accumulator Multiplies				
operand	bytes	8088	186	286	386	486	Pentium
r8	2	80-98	25-28	13	9-14	13-18	11 NP
r16	2	128-154	34-37	21	9-22	13-26	11 NP
r32	2	-	-	-	9-38	13-42	10 NP
mem8	2+d(0-2)	86-104+EA	32-34	16	12-17	13-18	11 NP
mem16	2+d(0-2)	134-160+EA	40-43	24	12-25	13-26	11 NP
mem32	2+d(0-2)	-	-	-	12-41	13-42	10 NP

implied operand result
multiplicand (multiplier)

AL * byte = AX
AX * word = DX:AX
EAX * dword = EDX:EAX

Example: imul ebx

			2 and 3 operand Multiplies				
operands	bytes	186	286	386	486	Pentium	
r16, imm	2+i(1,2)	-	21	9-14/9-22	13-18/13-26	10 NP	
r32, imm	2+i(1,2)	-	-	9-38	13-42	10 NP	
r16,r16,imm	2+i(1,2)	22/29	21	9-14/9-22	13-18/13-26	10 NP	
r32,r32,imm	2+i(1,2)	-	-	9-38	13-42	10 NP	
r16,m16,imm	2+d(0-2)	25/32	24	12-17/12-25	13-18/13-26	10 NP	
	+i(1,2)						
r32,m32,imm	2+d(0-2)+i(1,2)	-	-	12-41	13-42	10 NP	
r16, r16	2+i(1,2)	-	-	9-22	13-18/13-26	10 NP	
r32, r32	2+i(1,2)	-	-	9-38	13-42	10 NP	
r16, m16	2+d(0-2)+i(1,2)	-	-	12-25	13-18/13-26	10 NP	
r32, m32	2+d(0-2)+i(1,2)	-	-	12-41	13-42	10 NP	

all forms: dest, src
 or

cycles for: byte/word
 dword

dest, src1, src2
 Example: imul eax, ebx, 10

IN Input from port

operands	bytes	8088	186	286	386	486	Pentium
al, imm8	2	14	10	5	12	14	7 NP
ax, imm8	2	14	10	5	12	14	7 NP
eax, imm8	2	-	-	-	12	14	7 NP
al, dx	1	12	8	5	13	14	7 NP
ax, dx	1	12	8	5	13	14	7 NP
eax, dx	1	-	-	-	13	14	7 NP

Protected mode

operands	bytes			386	486	Pentium
acc, imm	2			6/26/26	9/29/27	4/21/19 NP
acc, dx	1			7/27/27	8/28/27	4/21/19 NP

cycles for: CPL <= IOPL / CPL > IOPL / V86

Example: in al, dx

INC Increment

operand	bytes	8088	186	286	386	486	Pentium
r8	2	3	3	2	2	1	1 UV
r16	1	3	3	2	2	1	1 UV
r32	1	3	3	2	2	1	1 UV
mem	2+d(0,2)	23+EA	15	7	6	3	3 UV

Example: inc ebx

INS/INSB/INSW/INSD Input from port to string

variations	bytes	8088	186	286	386	486	Pentium
insb	1	-	14	5	15	17	9 NP
insw	1	-	14	5	15	17	9 NP
insd	1	-	-	-	15	17	9 NP

Protected Mode

bytes		386	486	Pentium
1		9/29/29	10/32/30	6/24/22 NP

cycles for: CPL <= IOPL / CPL > IOPL / V86

Example: rep insb

INT Call interrupt procedure

operands	bytes	8088	186	286	386	486	Pentium
3	1	72	45	23+m	33	26	13 NP
imm8	2	71	47	23+m	37	30	16 NP

Protected mode

bytes		8088	186	286	386	486	Pentium
1		-	-	(40-78)+m	59-99	44-71	27-82 NP

Example: int 21h

INTO Call interrupt procedure if overflow

bytes		8088	186	286	386	486	Pentium
1		4/73	4/48	3/24+m	3/35	3/28	4/13 NP

Protected mode

bytes			286	386	486	Pentium
1			(40-78)+m	59-99	44-71	27-56 NP

Task switch clocks not shown

Example: into

INVD Invalidate data cache (486+)

bytes		8088	186	286	386	486	Pentium
2		-	-	-	-	4	15 NP

Example: invd

INVLPG Invalidate TLB entry (486+)

operands	bytes					486	Pentium
mem32	5					12	25 NP

Example: invlpg [eax]

IRET Return from interrupt

	bytes	8088	186	286	386	486	Pentium
	1	44	28	17+m	22	15	8-27 NP

Task switch clocks not shown

Example: iret

IRETD 32-bit return from interrupt (386+)

	bytes				386	486	Pentium
	1				22	15	10-27 NP

Task switch clocks not shown

Example: iretd

Jcc Jump on condition code

operand	bytes	8088	186	286	386	486	Pentium
near8	2	4/16	4/13	3/7+m	3/7+m	1/3	1 PV
near16	3	-	-	-	3/7+m	1/3	1 PV

cycles for: no jump/jump

conditional jump instructions:

ja	jump if above	jnb	jump if not below or equal
jae	jump if above or equal	jnb	jump if not below
jb	jump if below	jnae	jump if not above or equal
jbe	jump if below or equal	jna	jump if not above
jg	jump if greater	jnle	jump if not less or equal
jge	jump if greater or equal	jnl	jump if not less
jl	jump if less	jnge	jump if not greater or equal
jle	jump if less or equal	jng	jump if not greater
je	jump if equal	jz	jump if zero
jne	jump if not equal	jnz	jump if not zero
jc	jump if carry	jnc	jump if not carry
js	jump if sign	jns	jump if not sign
jnp	jump if no parity (odd)	jpo	jump if parity odd
jo	jump if overflow	jno	jump if not overflow
jp	jump if parity (even)	jpe	jump if parity even

Example: jne not_equal

JCXZ/JECXZ Jump if CX/ECX = 0

operand	bytes	8088	186	286	386	486	Pentium
dest	2	6/18	5/16	4/8+m	5/9+m	5/8	5/6 NP
dest	2	-	-	-	5/9+m	5/8	5/6 NP

cycles for: no jump/jump

Example: jcxz cx_is_zero

JMP Unconditional jump

operand	bytes	8088	186	286	386	486	Pentium
short	2	15	13	7+m	7+m	3	1 PV
near	3	15	13	7+m	7+m	3	1 PV
far	5	15	13	11+m	12+m	17	3 NP
r16	2	11	11	7+m	7+m	5	2 NP
mem16	2+d(0,2)	18+EA	17	11+m	10+m	5	2 NP
mem32	2+d(4)	24+EA	26	15+m	12+m	13	4 NP
r32	2	-	-	-	7+m	5	2 NP
mem32	2+d(0,2)	-	-	-	10+m	5	2 NP
mem48	2+d(6)	-	-	-	12+m	13	4 NP

cycles for jumps through call gates not shown

Example: jmp target_address

LAHF	Load flags into AH								
	bytes	8088	186	286	386	486		Pentium	
	1	4	2	2	2	3		2	NP
	Example:	lahf							
LAR	Load access rights byte (286+)								
operands	bytes			286	386	486		Pentium	
r16, r16	3			14	15	11		8	NP
r32, r32	3			-	15	11		8	NP
r16, m16	3			16	16	11		8	NP
r32, m32	3			-	16	11		8	NP
	Example:	lar	eax, ebx						
LDS	Load far pointer								
operands	bytes	8088	186	286	386	486		Pentium	
reg, mem	2+d(2)	24+EA	18	7	7	6		4	NP
	Example:	lds	si, ptr_1						
LES	Load far pointer								
operands	bytes	8088	186	286	386	486		Pentium	
reg, mem	2+d(2)	24+EA	18	7	7	6		4	NP
	Example:	les	di, ptr_2						
LFS	Load far pointer (386+)								
operands	bytes				386	486		Pentium	
reg, mem	3+d(2,4)				7	6		4	NP
	Example:	lfs	si, ptr_3						
LGS	Load far pointer (386+)								
operands	bytes				386	486		Pentium	
reg, mem	3+d(2,4)				7	6		4	NP
	Example:	lgs	si, ptr_4						
LSS	Load stack segment and offset								
operands	bytes				386	486		Pentium	
reg, mem	3+d(2,4)				7	6		4	NP
	Example:	lss	bp, ptr_5						
LEA	Load effective address								
operands	bytes	8088	186	286	386	486		Pentium	
r16, mem	2+d(2)	2+EA	6	3	2	1-2		1	UV
r32, mem	2+d(2)	-	-	-	2	1-2		1	UV
	Example:	lea	eax, [eax+ebx*2+3]						
LEAVE	High level procedure exit (186+)								
	bytes		186	286	386	486		Pentium	
	1		8	5	4	5		3	NP
	Example:	leave							
LGDT	Load global descriptor table register (286+)								
operand	bytes			286	386	486		Pentium	
mem48	5			11	11	11		6	NP
	Example:	lgdt	descriptor[ebx]						
LIDT	Load interrupt descriptor table register (286+)								
operand	bytes			286	386	486		Pentium	
mem48	5			12	11	11		6	NP
	Example:	lidt	descriptor[ebx]						
LLDT	Load local descriptor table register (286+)								
operand	bytes			286	386	486		Pentium	

r16	3		17	20	11	9	NP
mem16	3+d(0-2)		19	24	11	9	NP
Example: lldt ax							

LMSW Load machine status word (286+)

operand	bytes		286	386	486		Pentium
r16	3		3	10	13	8	NP
mem16	3+d(0-2)		6	13	13	8	NP
Example: lmsw ax							

LOCK Lock bus on next instruction (prefix)

	bytes	8088	186	286	386	486	Pentium
	1	2	2	0	0	1	1 NP

(Note: xchg always is locked whether it is specified or not)

Example: lock mov mem, 1

LODS/LODSB/LODSW/LODSD Load string operand

variations	bytes	8088	186	286	386	486	Pentium
lods	1	16	10	5	5	5	2 NP
lodsw	1	16	10	5	5	5	2 NP
lodsd	1	-	-	-	5	5	2 NP
Example: lods							

LOOP Loop control with CX counter

operand	bytes	8088	186	286	386	486	Pentium
short	2	5/17	5/15	4/8+m	11+m	6/7	5/6 NP

loopw short (uses CX in 32-bit mode)
loopd short (uses ECX in 16-bit mode)

Example: loop loop_start

LOOPE/LOOPZ Loop while equal (or zero)

operand	bytes	8088	186	286	386	486	Pentium
short	2	6/18	5/16	4/8	11+m	6/9	7/8 NP

loopew short (uses CX in 32-bit mode)
loopzw short (uses CX in 32-bit mode)
looped short (uses ECX in 16-bit mode)
loopzd short (uses ECX in 16-bit mode)

Example: loope loop_start

LOOPNE/LOOPNZ Loop while not equal (or not zero)

operand	bytes	8088	186	286	386	486	Pentium
short	2	5/19	5/16	4/8	11+m	6/9	7/8 NP

loopnew short (uses CX in 32-bit mode)
loopnzw short (uses CX in 32-bit mode)
loopned short (uses ECX in 16-bit mode)
loopnzd short (uses ECX in 16-bit mode)

Example: loopne loop_start

LSL Load segment limit (286+)

operands	bytes		286	386	486		Pentium
r16, r16	3		14	20/25	10	8	NP
r32, r32	3		-	20/25	10	8	
r16, m16	3+d(0,2)		16	21/26	10	8	
r32, m32	3+d(0,2)		-	21/26	10	8	
Example: lsl eax, ebx							

LTR Load task register (286+)

operand	bytes		286	386	486		Pentium
r16	3		17	23	20	10	NP
mem16	3+d(0,2)		19	27	20	10	
Example: ltr ax							

MOV		Move data						
operands	bytes	8088	186	286	386	486	Pentium	
reg, reg	2	2	2	2	2	1	1	UV
mem, reg	2+d(0-2)	13+EA	9	3	2	1	1	UV
reg, mem	2+d(0-2)	12+EA	12	5	4	1	1	UV
mem, imm	2+d(0-2) +i(1,2)	14+EA	12-13	3	2	1	1	UV*
reg, imm	2+i(1,2)	4	3-4	2	2	1	1	UV
acc, mem	3	14	8	5	4	1	1	UV
mem, acc	3	14	9	3	2	1	1	UV

* = not pairable if there is a displacement and immediate

Example: mov eax, ebx

Segment Register Moves

Real Mode

		Segment Register Moves						
operands	bytes	8088	186	286	386	486	Pentium	
seg, r16	2	2	2	2	2	3	2-11	NP
seg, m16	2+d(0,2)	12+EA	9	5	5	3	3-12	NP
r16, seg	2	2	2	2	2	3	1	NP
m16, seg	2+d(0,2)	13+EA	11	3	2	3	1	NP

Example: mov ds, ax

Protected Mode Differences

operands	bytes		286	386	486	Pentium	
seg, r16	2		17	18	9	2-11*	NP
seg, m16	2+d(0,2)		19	19	9	3-12*	NP

* = add 8 if new descriptor; add 6 if SS

MOVE to/from special registers (386+)

operands	bytes		386	486	Pentium	
r32, cr32	3		6	4	4	NP
cr32, r32	3		4/10*	4/16*	12/22*	NP
r32, dr32	3		14/22*	10	2/12*	NP
dr32, r32	3		16/22*	11	11/12*	NP
r32, tr32	3		12	3/4*	-	NP
tr32, r32	3		12	4/6*	-	NP

* = cycles depend on which special register

Example: mov cr0, eax

MOVS/MOVSb/MOVSW/MOVSd **Move data from string to string**

variations	bytes	8088	186	286	386	486	Pentium	
movsb	1	18	9	5	7	7	4	NP
movsw	1	26	9	5	7	7	4	NP
movsd	1	-	-	-	7	7	4	NP
rep movsb	2	9+17n	8+8n	5+4n	7+4n	12+3n*	3+n	NP
rep movsw	2	9+25n	8+8n	5+4n	7+4n	12+3n*	3+n	NP
rep movsd	2	-	-	-	7+4n	12+3n*	3+n	NP

* = 5 if n=0, 13 if n=1

(n = count of bytes, words or dwords)

Example: rep movsb

MOVSX **Move with sign-extend (386+)**

operands	bytes		386	486	Pentium	
reg, reg	3		3	3	3	NP
reg, mem	3+d(0,1,2,4)		6	3	3	NP

(Note: destination reg is 16 or 32-bits; source is 8 or 16 bits)

Example: movsx ebx, ax

MOVZX **Move with zero-extend (386+)**

operands	bytes		386	486	Pentium	
reg, reg	3		3	3	3	NP
reg, mem	3+d(0,1,2,4)		6	3	3	NP

(Note: destination reg is 16 or 32-bits; source is 8 or 16 bits)

Example: movzx ebx, ax

MUL Unsigned multiply

operand	bytes	8088	186	286	386	486	Pentium
r8	2	70-77	26-28	13	9-14	13-18	11 NP
r16	2	118-133	35-37	21	9-22	13-26	11 NP
r32	2	-	-	-	9-38	13-42	10 NP
mem8	2+d(0-2)	76-83+EA	32-34	16	12-17	13-18	11 NP
mem16	2+d(0-2)	124-139+EA	41-43	24	12-25	13-26	11 NP
mem32	2+d(0-2)	-	-	-	12-41	13-42	10 NP

implied operand result
multiplicand (multiplier)
AL * byte = AX
AX * word = DX:AX
EAX * dword = EDX:EAX
Example: mul ebx

NEG Two's complement negation

operand	bytes	8088	186	286	386	486	Pentium
reg	2	3	3	2	2	1	1 NP
mem	2+d(0-2)	24+EA	13	7	6	3	3 NP

Example: neg eax

NOP No operation

	bytes	8088	186	286	386	486	Pentium
	1	3	3	3	3	1	1 UV

Example: nop

NOT One's complement negation

operands	bytes	8088	186	286	386	486	Pentium
reg	2	3	3	2	2	1	1 NP
mem	2+d(0-2)	24+EA	13	7	6	3	3 NP

Example: not eax

OR Logical inclusive or

operands	bytes	8088	186	286	386	486	Pentium
reg, reg	2	3	3	2	2	1	1 UV
mem, reg	2+d(0,2)	24+EA	10	7	7	3	3 UV
reg, mem	2+d(0,2)	13+EA	10	7	6	2	2 UV
reg, imm	2+i(1,2)	4	4	3	2	1	1 UV
mem, imm	2+d(0,2)	23+EA	16	7	7	3	3 UV*
	+i(1,2)						
acc, imm	1+i(1,2)	4	4	3	2	1	1 UV

* = not pairable if there is a displacement and immediate

Example: or eax, ebx

OUT Output to port

operands	bytes	8088	186	286	386	486	Pentium
imm8, al	2	14	9	3	10	16	12 NP
imm8, ax	2	14	9	3	10	16	12 NP
imm8, eax	2	-	-	-	10	16	12 NP
dx, al	1	12	7	3	11	16	12 NP
dx, ax	1	12	7	3	11	16	12 NP
dx, eax	1	-	-	-	11	16	12 NP

Protected Mode

operands	bytes				386	486	Pentium
imm8, acc	2				4/24/24	11/31/29	9/26/24 NP
dx, acc	1				5/25/25	10/30/29	9/26/24 NP

cycles for: CPL <= IOPL / CPL > IOPL / V86

Example: out dx, al

OUTS/OUTSB/OUTSW/OUTSD **Output string to port**

variations	bytes	186	286	386	486	Pentium
outsb	1	14	5	14	17	13 NP
outsw	1	14	5	14	17	13 NP
outsd	1	-	-	14	17	13 NP

Protected Mode

bytes	386	486	Pentium
1	8/28/28	10/32/30	10/27/25 NP

cycles for: CPL <= IOPL / CPL > IOPL / V86

Example: rep outsw

POP **Pop a word/dword from the stack**

operand	bytes	8088	186	286	386	486	Pentium
reg	1	12	10	5	4	1	1 UV
mem	2+d(0-2)	25+EA	20	5	5	6	3 NP
seg	1	12	8	5	7	3	3 NP
FS/GS	2	-	-	-	7	3	3 NP

Protected Mode

operand	bytes	286	386	486	Pentium
CS/DS/ES	1	20	21	9	3-12 NP
SS	1	20	21	9	8-17 NP
FS/GS	2	-	21	9	3-12 NP

Example: pop eax

POPA/POPAD **Pop all (186+)/Pop all double (386+)**

variations	bytes	186	286	386	486	Pentium
popa	1	51	19	24	9	5 NP
popad	1	-	-	24	9	5 NP

popa = pop di, si, bp, sp, bx, dx, cx, ax

popad = pop edi, esi, ebp, esp, ebx, edx, ecx, eax

(sp and esp are discarded)

Example: popa

POPF/POPFD **Pop flags/Pop flags double (386+)**

variations	bytes	8088	186	286	386	486	Pentium
popf	1	12	8	5	5	9	6 NP
popfd	1	-	-	-	5	9	6 NP

Protected Mode

bytes	286	386	486	Pentium	
popf	1	5	5	6	4 NP
popfd	1	-	5	6	4 NP

Example: popf

PUSH **push a word/dword to the stack**

operand	bytes	8088	186	286	386	486	Pentium
reg	1	15	10	3	2	1	1 UV
mem	2+d(0-2)	24+EA	16	5	5	4	2 NP
seg	1	14	9	3	2	3	1 NP
imm	1+i(1,2)	-	-	3	2	1	1 NP
FS/GS	2	-	-	-	2	3	1 NP

Example: push eax

PUSHA/PUSHAD **Push all (186+)/Push all double (386+)**

variations	bytes	186	286	386	486	Pentium
pusha	1	36	17	18	11	5 NP
pushad	1	-	-	18	11	5 NP

pusha = push ax, cx, dx, bx, sp, bp, si, di,

pushad = push eax, ecx, edx, ebx, esp, ebp, esi, edi

Example: pusha

PUSHF/PUSHFD **Push flags/Push flags double (386+)**

variations	bytes	8088	186	286	386	486	Pentium
pushf	1	14	9	3	4	4	9 NP
pushfd	1	-	-	-	4	4	9 NP

Protected Mode

	bytes			286	386	486	Pentium
pushf	1			3	4	3	3 NP
pushfd	1			-	4	3	3 NP

Example: pushf

RCL Rotate bits left with CF

operands	bytes	8088	186	286	386	486	Pentium
reg, 1	2	2	2	2	9	3	1 PU
mem, 1	2+d(0,2)	23+EA	15	7	10	4	3 PU
reg, cl	2	8+4n	5+n	5+n	9	8-30	7-24 NP
mem, cl	2+d(0,2)	28+EA+4n	17+n	8+n	10	9-31	9-26 NP
reg, imm	3	-	5+n	5+n	9	8-30	8-25 NP
mem, imm	3+d(0,2)	-	17+n	8+n	10	9-31	10-27 NP

Example: rcl eax, 16

RCR Rotate bits right with CF

operands	bytes	8088	186	286	386	486	Pentium
reg, 1	2	2	2	2	9	3	1 PU
mem, 1	2+d(0,2)	23+EA	15	7	10	4	3 PU
reg, cl	2	8+4n	5+n	5+n	9	8-30	7-24 NP
mem, cl	2+d(0,2)	28+EA+4n	17+n	8+n	10	9-31	9-26 NP
reg, imm	3	-	5+n	5+n	9	8-30	8-25 NP
mem, imm	3+d(0,2)	-	17+n	8+n	10	9-31	10-27 NP

Example: rcr eax, 16

ROL Rotate bits left

operands	bytes	8088	186	286	386	486	Pentium
reg, 1	2	2	2	2	3	3	1 PU
mem, 1	2+d(0,2)	23+EA	15	7	7	4	3 PU
reg, cl	2	8+4n	5+n	5+n	3	3	4 NP
mem, cl	2+d(0,2)	28+EA+4n	17+n	8+n	7	4	4 NP
reg, imm	3	-	5+n	5+n	3	2	1 PU
mem, imm	3+d(0,2)	-	17+n	8+n	7	4	3 PU*

* = not pairable if there is a displacement and immediate

Example: rol eax, 16

ROR Rotate bits right

operands	bytes	8088	186	286	386	486	Pentium
reg, 1	2	2	2	2	3	3	1 PU
mem, 1	2+d(0,2)	23+EA	15	7	7	4	3 PU
reg, cl	2	8+4n	5+n	5+n	3	3	4 NP
mem, cl	2+d(0,2)	28+EA+4n	17+n	8+n	7	4	4 NP
reg, imm	3	-	5+n	5+n	3	2	1 PU
mem, imm	3+d(0,2)	-	17+n	8+n	7	4	3 PU*

* = not pairable if there is a displacement and immediate

Example: ror eax, 16

RDMSR Read from model specific register (Pentium+)

	bytes						Pentium
	2						20-24 NP

Example: rdmsr

REP Repeat string operation

See: MOVS (rep movs) move block
 See: STOS (rep stos) fill block

REPE Repeat while equal (or zero) string operation

See: CMPS (repe cmps) find non-matching memory items
 See: CMPS (repe scas) find non-acc matching byte in memory

REPNE Repeat while not equal (or not zero) string operation

See: CMPS (repne cmps) find first matching memory items
 See: SCAS (repne scas) find first matching memory item to acc

RET/RETN/RETF Return from procedure

variations/ operands	bytes	8088	186	286	386	486	Pentium
retn	1	20	16	11+m	10+m	5	2 NP
retn imm16	1+d(2)	24	18	11+m	10+m	5	3 NP
retf	1	34	22	15+m	18+m	13	4 NP
retf imm16	1+d(2)	33	25	15+m	18+m	14	4 NP

RET is coded by the assembler as near or far based on the procedure declaration and program model, as:

RETN (return near)

RETF (return far)

Example: ret

Protected Mode

variations/ operands	bytes		286	386	486	Pentium
retf	1		25+m/55	32+m/62	18/33	4-13/23 NP
retf imm16	1+d(2)		25+m/55	32+m/68	17/33	4-13/23 NP

cycles for: same privilege level/lower privilege level

RSM Resume from system management mode (Pentium+)

	bytes					Pentium
	2					83 NP

Example: rsm

SAL/SHL/SAR/SHR Shift bits

operands	bytes	8088	186	286	386	486	Pentium
reg, 1	2	2	2	2	3	3	1 PU
mem, 1	2+d(0,2)	23+EA	15	7	7	4	3 PU
reg, cl	2	8+4n	5+n	5+n	3	3	4 NP
mem, cl	2+d(0,2)	28+EA+4n	17+n	8+n	7	4	4 NP
reg, imm	3	-	5+n	5+n	3	2	1 PU
mem, imm	3+d(0,2)	-	17+n	8+n	7	4	3 PU*

* = not pairable if there is a displacement and immediate

sal = shift arithmetic left sar = shift arithmetic right

shl = shift left (same as sal) shr = shift right

Example: shl eax, 1

SAHF Store AH into flags

	bytes	8088	186	286	386	486	Pentium
	1	4	3	2	3	2	2 NP

Example: sahf

SBB Integer subtraction with borrow

operands	bytes	8088	186	286	386	486	Pentium
reg, reg	2	3	3	2	2	1	1 PU
mem, reg	2+d(0,2)	24+EA	10	7	7	3	3 PU
reg, mem	2+d(0,2)	13+EA	10	7	6	2	2 PU
reg, imm	2+i(1,2)	4	4	3	2	1	1 PU
mem, imm	2+d(0,2)	23+EA	16	7	7	3	3 PU*
	+i(1,2)						
acc, imm	1+i(1,2)	4	4	3	2	1	1 PU

* = not pairable if there is a displacement and immediate

Example: sbb eax, ebx

SCAS/SCASB/SCASW/SCASD		Scan string data						
variations	bytes	8088	186	286	386	486	Pentium	
scasb	1	19	15	7	7	6	4 NP	
scasw	1	19	15	7	7	6	4 NP	
scasd	1	-	-	-	7	6	4 NP	
repX scasb	2	9+15n	5+15n	5+8n	5+8n	7+5n*	8+4n NP	
repX scasw	2	9+19n	5+15n	5+8n	5+8n	7+5n*	8+4n NP	
repX scasd	2	-	-	-	5+8n	7+5n*	8+4n NP	

repX = repe or repz or repne or repnz

* = 5 if n=0

(n = count of bytes, words or dwords)

Example: repne scasb

SET Set byte to 1 on condition else set to 0 (386+)

operand	bytes	386	486	Pentium
r8	3	4	4/3	1/2 NP
mem8	3+d(0-2)	5	3/4	1/2 NP

Cycles are for: true/false

setCC = one of:

```
seta    setae    setb    setbe    setc    sete
setg    setge    setl    setle    setna   setnae
setnb   setnbe    setnc   setne    setng   setnge
setnl   setnle    setno   setnp    setns   setnz
seto    setp    setpe   setpo    sets    setz
```

Example: setne al

SGDT Store global descriptor table register (286+)

operand	bytes	286	386	486	Pentium
mem48	5	11	9	10	4 NP

Example: sgdt descriptor[ebx]

SIDT Store interrupt descriptor table register (286+)

operand	bytes	286	386	486	Pentium
mem48	5	12	9	10	4 NP

Example: sidt descriptor[ebx]

SHLD Double precision shift left (386+)

operands	bytes	386	486	Pentium
reg, reg, imm	4	3	2	4 NP
mem, reg, imm	4+d(0-2)	7	3	4 NP
reg, reg, cl	4	3	3	4 NP
mem, reg, cl	4+d(0-2)	7	4	5 NP

Example: shld eax, ebx, 16

SHRD Double precision shift right (386+)

operands	bytes	386	486	Pentium
reg, reg, imm	4	3	2	4 NP
mem, reg, imm	4+d(0-2)	7	3	4 NP
reg, reg, cl	4	3	3	4 NP
mem, reg, cl	4+d(0-2)	7	4	5 NP

Example: shrd eax, ebx, 16

SLDT Store local descriptor table register (286+)

operands	bytes	286	386	486	Pentium
r16	3	2	2	2	2 NP
mem16	3+d(0-2)	3	2	3	2 NP

Example: sldt ax

SMSW Store machine status word (286+)

operands	bytes	286	386	486	Pentium
r16	3	2	2	2	4 NP

	mem16	3+d(0-2)		3	3	3	4	NP
	Example:	smsw	ax					
STC	Set the carry flag							
	bytes	8088	186	286	386	486		Pentium
		1	2	2	2	2	2	NP
	Example:	stc						
STD	Set direction flag (set to reverse string direction)							
	bytes	8088	186	286	386	486		Pentium
		1	2	2	2	2	2	NP
	Example:	std						
STI	Set interrupt flag (enable)							
	bytes	8088	186	286	386	486		Pentium
		1	2	2	3	5	7	NP
	Example:	sti						
STOS/STOSB/STOSW/STOSD	Store string data							
	variations	bytes	8088	186	286	386	486	Pentium
	stosb	1	11	10	3	4	5	3 NP
	stosw	1	15	10	3	4	5	3 NP
	stosd	1	-	-	-	4	5	3 NP
	rep stosb	2	9+10n	6+9n	4+3n	5+5n	7+4n*	3+n NP
	rep stosw	2	9+14n	6+9n	4+3n	5+5n	7+4n*	3+n NP
	rep stosd	2	-	-	-	5+5n	7+4n*	3+n NP
			* = 5 if n=0, 13 if n=1					
			(n = count of bytes, words or dwords)					
	Example:	rep	stosd					
STR	Store task register (286+)							
	operand	bytes		286	386	486		Pentium
	r16	3		2	2	2	2	NP
	mem16	3+d(0-2)		3	2	3	2	NP
	Example:	str	bx					
SUB	Integer subtraction							
	operands	bytes	8088	186	286	386	486	Pentium
	reg, reg	2	3	3	2	2	1	1 UV
	mem, reg	2+d(0,2)	24+EA	10	7	7	3	3 UV
	reg, mem	2+d(0,2)	13+EA	10	7	6	2	2 UV
	reg, imm	2+i(1,2)	4	4	3	2	1	1 UV
	mem, imm	2+d(0,2)	23+EA	16	7	7	3	3 UV*
		+i(1,2)						
	acc, imm	1+i(1,2)	4	4	3	2	1	1 UV
			* = not pairable if there is a displacement and immediate					
	Example:	sub	eax, ebx					
TEST	Logical compare							
	operands	bytes	8088	186	286	386	486	Pentium
	reg, reg	2	3	3	2	2	1	1 UV
	mem, reg	2+d(0,2)	13+EA	10	6	5	2	2 UV
	reg, mem	2+d(0,2)	13+EA	10	6	5	2	2 UV
	reg, imm	2+i(1,2)	5	4	3	2	1	1 UV
	mem, imm	2+d(0,2)	11+EA	10	6	5	2	2 UV*
		+i(1,2)						
	acc, imm	1+i(1,2)	4	4	3	2	1	1 UV
			* = not pairable if there is a displacement and immediate					
	Example:	sub	eax, ebx					
VERR	Verify a segment for reading (286+)							
	operand	bytes		286	386	486		Pentium
	r16	3		14	10	11	7	NP

	mem16	3+d(0,2)		16	11	11	7	NP
	Example:	verr	ax					
VERW	Verify a segment for writing (286+)							
	operand	bytes		286	386	486		Pentium
	r16	3		14	15	11	7	NP
	mem16	3+d(0,2)		16	16	11	7	NP
	Example:	verr	ax					
WAIT	Wait for co-processor							
		bytes	8088	186	286	386	486	Pentium
			1	4	6	3	6	1-3 1 NP
	Example:	wait						
WBINVD	Write-back and invalidate data cache (486+)							
		bytes				486		Pentium
			2			5		2000+ NP
	Example:	wbinvd						
WRMSR	Write to model specific register (PENTIUM+)							
		bytes						Pentium
			2					30-45 NP
	Example:	wrmsr						
XADD	Exchange and add (486+)							
	operands	bytes				486		Pentium
	reg, reg	3				3	3	NP
	mem, reg	3+d(0-2)				4	4	NP
	Example:	xadd	eax, ebx					
XCHG	Exchange register/memory with register							
	operands	bytes	8088	186	286	386	486	Pentium
	reg, reg	2	4	4	3	3	3	3 NP
	reg, mem	2+d(0-2)	25+EA	17	5	5	5	3 NP
	mem, reg	2+d(0-2)	25+EA	17	5	5	5	3 NP
	acc, reg	1	3	3	3	3	3	2 NP
	reg, acc	1	3	3	3	3	3	2 NP
	in above: acc = AX or EAX only							
	Example:	xchg	ax, dx					
XLAT/XLATB	Table look-up translation							
		bytes	8088	186	286	386	486	Pentium
			1	11	11	5	5	4 4 NP
	Example:	xlat						
XOR	Logical exclusive or							
	operands	bytes	8088	186	286	386	486	Pentium
	reg, reg	2	3	3	2	2	1	1 UV
	mem, reg	2+d(0,2)	24+EA	10	7	7	3	3 UV
	reg, mem	2+d(0,2)	13+EA	10	7	6	2	2 UV
	reg, imm	2+i(1,2)	4	4	3	2	1	1 UV
	mem, imm	2+d(0,2)	23+EA	16	7	7	3	3 UV*
		+i(1,2)						
	acc, imm	1+i(1,2)	4	4	3	2	1	1 UV
	* = not pairable if there is a displacement and immediate							
	Example:	xor	eax, ebx					